

# HERMES

Homing Pigeon Breeding Boxes

## ASSEMBLY INSTRUCTIONS FOR BREEDING BOXES

1



If the box is delivered with a rear panel, insert the panel in the grooves at the back of the side panels. Then, from the top to the bottom, push the rear crossbars with the dimensions 19 x 27 mm onto the metal bolts on the side walls. 4 bars in total. In doing so, the holes can also point to the back as they are not needed for breeding boxes.

2



Hang the base panels in the holes provided for this.

3



The beech wood perch bars are marked on the end face with (I) and (II). The bars marked with (I) are fitted in the bottom section rows. The slot must point to the front and the round hole to the back.

# HERMES

Homing Pigeon Breeding Boxes

## ASSEMBLY INSTRUCTIONS FOR BREEDING BOXES

4



The bars marked with (II) are needed for the middle section rows.

5



For the top row the bars marked with (I) are needed again.

6



Now the wire meshes are fitted. The folds must point downwards.

# HERMES

Homing Pigeon Breeding Boxes

## ASSEMBLY INSTRUCTIONS FOR BREEDING BOXES

7



With the upright side panels, the plastic hooks for the top panel (cover) must be screwed only into the middle panels.

8



Fit the intermediate floor for the second clutch onto the angled hooks on the side panels. The rounded corner of the intermediate floors must point to the front.

9



There are two different variants. (For the top and bottom section rows, left-handed are required, for the middle section rows, right-handed.)

# HERMES

Homing Pigeon Breeding Boxes

## ASSEMBLY INSTRUCTIONS FOR BREEDING BOXES

10



Now lay out the coloured front doors.

11



To every coloured door there belongs a contrasting front door with vertical bars.

12



Fit the coloured doors onto the plastic hooks on the upright side panels.

# HERMES

Homing Pigeon Breeding Boxes

## ASSEMBLY INSTRUCTIONS FOR BREEDING BOXES



13

Fit the front door with the round bars onto the bar with the two plastic hooks. In doing so, the sliding bolt must always point to the outside.



14

Hang the front bar together with the front door in the mounting bracket.



15

Repeat this for all of the sections.

# HERMES

Homing Pigeon Breeding Boxes

## ASSEMBLY INSTRUCTIONS FOR BREEDING BOXES

16



Fit the top panel from above. The polished edge must point to the front.

17



Insert the droppings floors. Afterwards, accurately align the box vertically and horizontally using the spirit level and screw it securely to the back wall.

18



The intermediate floor can be used for the second clutch.

# HERMES

Homing Pigeon Breeding Boxes

## ASSEMBLY INSTRUCTIONS FOR BREEDING BOXES



19

A dividing door with a walkthrough can also be delivered as an option.



20

This means that during mating, the cock and the hen can be confined separated from each other.

